FIT INSTRUCTIONS 0 ŕ Ш \mathbf{C}

SS17/20 BRUSH HEAD STABILIZER

KIT #190937

- Empty recovery and solution tanks. Remove squeegee assembly and pad driver.
- Remove batteries.
- Disconnect brush motor leads. Cut any wier ties that hold brush motor leads.
- Tip machine upside down.
- Cut any wire ties holding wiring or solution hose to lift bracket item #85.
- Remove wheels.
- Remove screws item #69 and remove axle.
- Remove screw item #70 to disconnect brush lift lever item #119 from lift bracket item #85.
- Remove solution hose item #24 from motor mount bracket item #20.
- 10. Remove (4) screws item #68 and remove entire assembly from machine.
- 11. Remove drive plate item #32 by removing screw item #35.
- 12. Remove brush motor item #16 by removing (4) screws #31.
- 13. Remove spring item #84 and attach to new assembly.
- Remove bumper item #18 and attach to new assembly.
- 15. Assembly motor to new assembly.
- 16. Assemble drive plate to motor shaft.
- 17. Assemble new assembly to machine.
- 18. Re-attach solution hose to motor mount bracket.
- 19. Re-attach brush lift lever to lift bracket.
- 20. Re-assemble axle and wheels.
- 21. Re-assemble springs item #61 and screws item #69.
- 22. Re-wire tie solution hose and wiring to lift bracket.
- 23. Tip machine right side up.
- Load batteries.
- 25. Re-wire motor leads and wire tie wiring to clear vac motor.



PARTS DIAGRAM

