



CONVERSION KIT

INSTALLATION INSTRUCTIONS:

(Installation Time: 1/2 hour)

TOOLS REQUIRED: 9/16" Socket Wrench

FOR SAFETY: Before installing kit, disconnect positive (+) battery cable from batteries.

1. Remove squeegee assembly, skirt assemblies and pad drivers.
2. Using a 9/16" socket wrench loosen (4) hex head screws that mount brush motors to motor bracket (See Diagram Detail).
Slide motors completely inward for 24" conversion and outward for 26" conversion. Tighten screws after adjusting.
3. Mount new pad drivers, skirt assemblies and squeegee assembly.
4. Replace Model Number side decals.

NOTE: Parts removed create the complete conversion kit part no. for the opposite model size.

602898 & 602899 CONVERSION KIT CONTENTS

602898 kit (24")	602899 kit (26")	Description	Qty.
602807	602809	Skirt Assembly, LH, Gray	1
602808	602810	Skirt Assembly, RH, Gray	1
603262	603263	Squeegee Assembly	1
240262	602928	Driver, Pad (set of 2)	1
602854	602855	Decal, Model No.	2

609769 & 609768 CONVERSION KIT CONTENTS

609769 kit (24")	609768 kit (26")	Description	Qty.
609773	609771	Skirt Assembly, LH, Spruce	1
609772	609770	Skirt Assembly, RH, Spruce	1
603262	603263	Squeegee Assembly	1
240262	602928	Driver, Pad (set of 2)	1
608450	608449	Decal, Model No.	2

609794 & 609793 CONVERSION KIT CONTENTS

609794 kit (24")	609793 kit (26")	Description	Qty.
609798	609796	Skirt Assembly, LH, Teal	1
609797	609795	Skirt Assembly, RH, Teal	1
603262	603263	Squeegee Assembly	1
240262	602928	Driver, Pad (set of 2)	1
608118	608119	Decal, Model No.	2

