



Actuator Kit, Repl.

Models: 7080 / EZ Rider HP



ADJUSTMENT PROCEDURE:

TOOLS REQUIRED: measuring tool

BEFORE INSTALLING ACTUATOR:

1. Plug actuator's power cord into the machine.
2. Activate the squeegee "down" switch to run the actuator out to the fully extended position.
3. Activate the squeegee "up" switch to run the actuator back to the fully retracted position.
(Steps 2 and 3 set the actuator's limit switches).
4. Manually rotate the actuator shaft as required to a distance of 0.370"/9.4mm (3/8") from the actuator housing, as shown (see photo).

INSTALLING ACTUATOR:

5. Install new actuator to machine - squeegee must be in the down position. You may need to rotate the actuator shaft slightly for proper alignment to install the retaining pin.
6. Run the squeegee up and down to be sure the actuator is properly adjusted.

Kit Contents

Part No.	Description	Qty.
390989	Actuator, 36vdc, 02.0 Strk, 300lb.	1

