




# Technical Service Bulletin

MODEL(S)  
AFFECTED: **Tennant 5700XP (serial numbers 0022000-0025130)**


SUBJECT: Machines may move while charging if the operator forgets to turn off the key switch before charging the batteries.

PURPOSE: Prevent machine from moving while the batteries are charging.

NOTES: Operator must **turn off the machine before charging** (as stated in the Operator manual) before charging the batteries.  
Interlock kit contains parts that prevent the machine from moving if the key switch is left on while the batteries are charging.  
Order Interlock kit 9002011. The IB for this kit is 340805.  
Questions, contact the Tennant Customer Service Department at (800) 553-8033.



**FOR SAFETY: Before charging batteries, stop on level surface, set the parking brake (if equipped), and turn off machine.**



**New Interlock kit installed**