

Walk-Behind Scrubber

COMMON PARTS & CONSUMABLES

Only genuine Tennant parts can ensure peak performance for the life of your equipment.

Serial#

Brushes & pads

- Easy installation helps reduce machine downtime.
- Optimal operation with Tennant machines, maximizing cleaning effectiveness in one pass.

PART DESCRIPTION	PART #
Brush Disc 500mm Nylon	1016810
Brush Disc 500mm Polypropylene	1016811
White Pad Polishing, 20 inches / 510mm [5PC]	994545
Red Pad Buffing, 20 inches / 510mm [5PC]	995615
Blue Pad Scrubbing, 20 inches / 510mm [5PC]	995623

Battery & charger

PART DESCRIPTION	PART #
AGM Battery 12VDC,120AH (2 Required)	1274853
Offboard Battery Charger Kit	9030081
Charger power cord [2.5meter, CE]	1044068
Charger power cord [2.5meter, UK]	1044069

Squeegee

- Tennant offers three types of squeegee materials to best suit your needs.
 - Premium Linatex® rubber exhibits outstanding strength and resistance to cutting and tearing.
 - Chemical-resistant urethane has a long service life; well suited for use with organic and petroleum-based oils.
 - Economy Gum Rubber is cost-effective option for smooth, indoor floors, made of a combination of natural material and fillers.

PART DESCRIPTION	PART #
Blade Kit [Front-Rear], 500mm, Linatex	9015731
Blade Kit [Front-Rear], 500mm, Urethane	9015732
Blade Kit [Front-Rear], 500mm, Gum	9015730