



Ride-on sweeper

COMMON PARTS & CONSUMABLES

Only genuine Tennant parts can ensure peak performance for the life of your equipment.

Serial #

Brushes

- Easy installation helps reduce machine downtime.
- Optimal operation with Tennant machines, maximizing cleaning effectiveness in one pass.

PART DESCRIPTION	PART #
Cylindrical Brush, 700*320	TN5100322
Side Brush	TN5100320

General Maintenance

- TennantTrue® parts are designed to fit your Tennant machine, helping achieve better cleaning performance and reducing machine downtime.

PART DESCRIPTION	PART #
Filter	TN5100357
Filter, 80 Mesh	CN5004741
Circuit breaker, 3A, Insert	CN5004454
Circuit breaker, 10A, Insert	CN5006408
Fuse, 100A	CN5001636
Sealing Strip, W17, H30, 1-3.5MM	CN5006464
Hopper Wheel, 5 inches	TN4100405
Drive Belt, XPA800	CN4001190
Load-Bearing Wheel, 300*100MM	CN5006463
Side Skirt	TN5100354
Rear Skirt	CN5006432
Front Skirt	CN5006429
Ignition Key	CN5001519

Batteries and Chargers

- Match runtime and performance needs with the right power source.
- Sealed AGM battery for easy, no maintenance.

	PART DESCRIPTION	PART #
BATTERY	AGM, 12VDC, 120AH	1274853
CHARGER	48V, 15A (PFC1200), Y60	4235170