

Release Date:
July 20, 2021



Technical Service Bulletin

MODEL(S) AFFECTED: T390 Walk-Behind Floor Scrubber

Machines manufactured before serial number 1255469-00496 (July 07, 2021)

SUBJECT: Squeegee height adjustment may be required if end of squeegee blade is touching floor when raised to transport position as shown below.

PURPOSE: To prevent potential squeegee blade damage, adjust squeegee lift handle bracket as described below.

NOTES: **Warranty Information:** Standard warranty terms apply.

Squeegee Lift Handle Bracket Adjustment Instructions:

1. Lower the squeegee assembly to the floor.
2. Using an 8mm socket wrench, loosen the two m5 screws securing the lift handle bracket.
3. Adjust the lift handle bracket slightly upward and re-tighten the two screws.
4. Lift the squeegee assembly to the transport position and ensure the squeegee blades are no longer touching floor.

Adjust squeegee lift handle bracket



Transport position

