KIT NO. 610834 Page 1 of 1



BRUSH HANDLE & CLIP KIT

INSTALLATION INSTRUCTIONS:

(Installation Time: 15 minutes)

TOOLS REQUIRED: Philips Screwdriver, Power drill with 1-3/16 Boring Bit.

FOR SAFETY: Before installing kit, unplug cord from wall outlet.

- Replace brush handle with new handle.
- 2. Remove old brush handle clip from machine, save screws.
- Using a 1-3/16" boring bit, ream out brush handle hole at bottom of machine handle as shown. Be careful not to cut beyond first layer of plastic.
- 4. Install new brush handle clip.



