

Technical Service Bulletin

MODEL(S) AFFECTED: **Tennant M20 (serial numbers 000000-002747) and M30 (serial numbers 000000-001089)**

SUBJECT: Thermo-Sentry wires coming loose due to machine vibration.

PURPOSE: Secure Thermo-Sentry wires to increase reliability.

NOTES: Drill two 3/16" (5mm) holes into the hopper cover and use two cable ties to secure Thermo-Sentry wires to hopper cover.
Questions, contact the Tennant Customer Service Department at (800) 553-8033 or (763) 513-2850.
Warranty Information: Standard Terms Apply.

